


- AURALIS DB Instructions & Installation :



ITEMS:-

1. BOX SUB ASSEMBLY
2. EARTHING STUD
3. REMOVABLE DIN RAIL CHANNEL
4. INSERTION MARK
5. MCB
6. DOOR

- Assembly of AURALIS Metal Enclosure

1. Packing, Storage & Handling of DB

- AURALIS DB comes with individual packing for DB's safe storage and handling.
- Store DB main carton safely away from heat and water till DB's are required for installation in/on the wall.
- Open DB main packing only when required for installation.

2. DB Wall Box Installation

- Remove polybag from DB, Recycle / dispose it safely to protect our environment.
- Fix the DB box in/on the wall only up to the insertion mark provided as shown in the picture.
- Important Note: If the box is flush-mounted deeper than the insertion marking line, frame and door assembly cannot be installed properly.

3. MCB Assembly inside DB Box

- MCBs can be conveniently assembled on the DIN rail & Fix the entire assembly inside the DB.
- Always follow electrical safety requirements for wiring connections.

4. Door Installation

- Remove polybag from DB door. Recycle / dispose it safely to protect our environment.
- Put the door on the box and fix it with screws.

5. Safe & recommended installation practices

- Do not allow wet cement to dry or set on powder-coated surfaces of DB.
- If wet cement sets on powder coated surfaces during installation, Wipe such wet cement immediately by a clean dry cloth.
- Use of chisel or screwdriver to remove dried cement later will damage the powder coating surfaces and cause DB rusting.